

Installing K&N Filters

I've been asked to provide details on how I modified the front K&N Air cleaner on my BN6 to back it away from the hood opening bodywork.

The stock 5-3/4" wide x 1-3/4" high K&N air cleaner, when bolted to the front HD6 carb, is thick enough to be right next to the bodywork and in many cases will dent it when the engine rocks side to side. The one setup other than mine I've seen was also dented slightly.

I've prepared an Adobe Acrobat PDF drawing of the setup which is on the next page.

BN6-7 HD6 K&N Front Filter Modification.

Moves Filter 3/8" closer to Dashpot and away from car bodywork.

by Steve Gerow sgerow@singular.com 1/12/02

