

Select the white wire (9) from A3 on the fuse box, break it where physically convenient (or run new wires to/from the break), and insert the switch.

