

Top Frame Mount Screws

This picture courtesy of Doug Reid (18G Motorworks) of an unrestored BN1 shows exactly what you need from an original example. Note the 3 self tapping number 6 nickel finished trim screws with cup washers running parallel to the door pillar edge to locate the rear quarter trim panel. Then there is a standard male dome snap base located along side the top frame anchor plate. If you are fitting a top or already have one, you can see the size of the snap. This is used to hold down the tail flap of the top when it's erected. It is also held in place with a number 6 self tapping screw.

Hope this helps

Rich Chrysler

Hi again,

I was putting in the interior panels of the cockpit (100-4, BN1), specifically the panels that go behind the seats, that the top frame screws mount through. I'm not clear on what the Anderson/Moment book is saying regarding which holes in the panels (not the top frame screw holes) get screws and which get some kind (what kind) of snap or stud, I guess for securing the top fabric in some way. Clarity please. :)

**Sincerely,
Paul B.**

