

## **Installing a Flywheel Ring Gear**

### **A great tech tip.....**

To install on the flywheel, heat the ring gear in the oven (about 250 degrees)"

If your wife won't let you use the oven a gas barbecue is ideal for the job.

--

Regards,

Mike Salter